



1 inch (25 mm)

0.5 inch
(12 mm)

3.5 inch
(90 mm)

This is the notch for the TelRad switch lever.
1. Use hole punch to radius the corners of the notch.
2. Cut out shaded area.

Velcro*
(adhesive
backed)

*Alternately, dew shield may be attached to the
TelRad with painter's tape.